



## Program mode description

MODE	DESCRIPTION	BATTERY LIFE
1	Rainbow effect, slow + STROBE	Normal
2	Rainbow effect, fast	Normal
3	Violet	Normal
4	Emerald	Normal
5	Pink	Normal
6	Kosmos green	Normal
7	Light blue	Normal
8	Sequence (red, green, blue, violet) + STROBE	Long
9	Sequence pink-emerald + STROBE	Long
10	Sequence yellow, violet + STROBE	Long
11	Sequence blue - orange + STROBE	Long
12	Sequence red-sky blue + STROBE	Long
13	<b>DEMO Program</b> Shows program from 1 to 12, changing automatically every 15 seconds. Note: while in program mode, this program is identified by blinking red.	Long

Place of magnetic sensitive zone is opposite to the charging orifice.

